

1968 CAMARO FACTORY ASSEMBLY MANUAL

TABLE OF CONTENTS

BODY

- Fenders 135
- Hood hinge & cowl seal 136
- Header panel & grill upper 137
- Grill assembly 138
- Fender emblems 139
- Inner fenders 141
- Radiator support to fender & fender support rods 142
- Valance to fender & fender extension 143
- Hood catch & latch assembly 144
- Radiator & fan shroud 145
- Sheet metal gaps 146-147
- Battery tray 149
- Front bumper 178
- Rear bumper 179
- Rear bumper guards 180

BRAKES

- Master cylinder 70
- Brake pedal 71
- Front brake lines 72
- Rear brake lines 73
- Parking brake pedal & front cable 74
- Parking brake rear cables 75

ELECTRICAL & LIGHTING

- Battery Cables (V-8) 151-152
- Headlight & parking lamps 153
- Marker lamps 154
- Front lighting harness & junction block 155
- Alternator & regulator wiring 156
- Engine wiring (V-8) 158
- Headlight aiming 159
- Fuse block 160
- Instrument housing 161
- Instrument cluster lighting 162
- Dash harness 163-164
- Headlight switch & cigarette lighter 165
- Dimmer switch & brake light switch 166
- Courtesy lighting 167
- Parking brake switch 168
- Turn signal lever & horn cap 169
- Speedometer cable 171
- Rear license lamp 172
- Console wiring 233
- Heavy duty battery 381
- Radio ground straps 408
- Antenna 410-411

ENGINE COMPARTMENT

- Windshield wiper motor 36
- Cowl & wiper blades 37
- Washer jar 38
- Washer nozzle & hose routing 39
- Radiator hoses 87
- Starter 89
- Voltage regulator & ignition switch 92
- V-8 motor mounts 94
- V-8 fuel pump 99

EXTERIOR

- Rocker panel moldings 45
- Outside mirror 46
- Carpet & sill plates 47

FUEL SYSTEM & EXHAUST

- Gas tank 121
- Gas tank filler neck 122
- Fuel line & clips 123
- Fuel sending unit & rear hoses 124
- Dual exhaust hangars 360

HEATING & COOLING

- Astrovent system 51
- Heater box (inner & outer) 52
- Defroster duct 53
- Heater hoses 54
- Heater control 55
- Heater control cables 56

INTERIOR

- Firewall Pad 40
- Glove box & door 41
- Wiper switch & glove box lock 42
- Ash tray 43
- Rearview mirror, center dash panel & column covers 44
- Console assemble 229
- Console lid & ash tray 230
- Console floor shifter assembly (manual) 231
- Kick panel speakers 402
- Stereo 404
- Pedal trim plates 438

STEERING

- Steering linkage 126
- Steering box to column 127
- Steering column to firewall 128
- Steering wheel 129
- Steering column installation sequence 130
- Power steering 370
- Power steering bleeding 380

- Power steering hoses 374

SUSPENSION

- Body mounts 50
- Subframe 57
- Control arms (upper & lower) 59
- Spindle 60
- Coil spring & front shocks 64
- Sway bar hardware 62
- Front alignment geometry 63
- Drive line attachment 65
- Leaf spring front attachment 66
- Leaf spring to axle 67
- Rear shocks 68

TRANSMISSION

- Transmission mount 95
- Accelerator pedal assembly 103
- Cable type accelerator linkage (L-6) 104
- Throw out bearing 111
- Clutch pedal & linkage 112
- Clutch z-bar & pushrod assembly 113
- Clutch adjustment 114
- 4 Speed transmission 316-23